Application Note

63600 Timing Measurements:

L. Sharp

The Chroma 63600 Load Modules have an advanced feature called TIMING. This test will measure the time between 2 points these points are specified by a TRG_S (Trigger Start Voltage) and TRG_E (Trigger End Voltage) There are 3 different modes for this test and they are RISE Time, FALL Time, and HOLD-UP Time.

To set up and run this test is very easy the steps are listed below:

- Step 1 Select the Advanced Features on the 63600 Load Module by pressing the ADVA button. (Fig 1) Step 2 Select 1. TIMING by turning the rotary knob CW till TIMING is highlighted then press ENTER. Step 3 Press the EDIT button to change the settings for the timing test. (Fig 1) Press the ENTER button after changing each parameter in the timing test. Step 4 (Fig 1) Step 5 Exit editing the timing test by pressing the EDIT button again. Step 6 To activate the test hit the LOAD button and it will light up. (Fig 1) Step 7 Activate your UUT to create either a Rising turn on condition or a Falling turn off condition. Step 8 The reading on the display are more than 1 screen so to see all the measurements press the DATA key.
 - **FIG 1.0** Chromo DO ELECTRONIC LOAD **ADVANCE** TIMING 2. SINE WAVE DYNA 3. OCP TEST 4. AUTO SEQUENCE LOAD This button Activates the Load **EDIT** This button opens the edit mode Carrie County ENTER This button enter/stores settings ADVA This button opens the Advance menu

Following shows the setting for a RISE time test on a 12Vdc power supply. The measurement is set to measure the time it takes the output to go from 1.0Vdc to 11.0Vdc. The load is set to 5Amps in CC mode. The setting parameters for this test include TRIG_M (Trigger Mode); TRIG_S (Trigger Start Voltage); TRIG_E (Trigger End Voltage, T_OUT (Time Out or Maximum run time of test); MODE (select the load mode CC); I_SET (sets the current of the load); SR/ & SR\ (Slew rate of the load on the rising and falling edge.





Results of the above test: There are other measurements displayed such as VOLTAGE, CURRENT and Ampere Hours to see the Time measurement use the DATA button.



